Luxman

SERVICE MANUAL

Stereo Integrated Amplifier

LV-105u



www.manualscenter.com

Contents

Specifications ····· 3
Parts Locations and Disassembly Instructions ····· 4 to 9
Adjustment Procedures ····· 10
Adjustment Locations ····· 11
Block Diagram ····· 12
Schematic Diagram ····· 13 to 15
Parts Layout on P. C. Boards and Wiring Diagram (1/3) ····· 16 to 18
Parts Layout on P. C. Boards and Wiring Diagram (2/3) ····· 19 to 21
Parts Layout on P. C. Boards and Wiring Diagram (3/3) ····· 22 to 24
Electrical Parts List ····· 24 to 31
Cabinet Assembly Parts List ····· 32
Exploded View (Cabinet) ····· 33 to 34
Packing Assembly Parts List ····· 35
Packing Method View ····· 35
Parts List by the Destination ····· 36 to 38
Semi-Conductor Lead Identifications ····· 39 to 41

www.manualscenter.com

Specifications

Power Output	70W (0.25%THD at 20Hz~20KHz)
Headphones Output	(80W/8 ohm-1KHz) 650mV±10%
Input Sensitivity (1KHz)	CD : 150mV±15%
	Tuner : 150mV±15%
	Tape-1, 2 : 150mV±15%
	AV-1, 2 : 150mV±15%
	Adaptor : 150mV±15%
	Phono (MM) : 2mV±15%
	Phono (MC) : 150 μV±15%
Input Impedance (1KHz)	CD : 47K ohm±15%
	Tuner : 47K ohm±15%
	Tape-1, 2 : 47K ohm±15%
	AV-1, 2 : 47K ohm±15%
	Adaptor : 47K ohm±15%
	Phono (MM) : 47K ohm±15%
	Phono (MC) : 100 ohm±15%
Frequency Response	CD : 10-100KHz+0.6-2dB
	Tuner : 10-100KHz+0.6-2dB
	Tape-1, 2 : 10-100KHz+0.6-2dB
	Phono (MM) : 100Hz±0.5dB
	Phono (MC) : 10KHz±0.5dB
Signal to Noise Ratio (Input Shorted)	CD : 81.5dB
	Tuner : 81.5dB
	AV-1, 2 : 81.5dB
	Adaptor : 81.5dB
	Phono (MM) : 69.4dB
	Phono (MC) : 47.5dB
Cross Talk	CD : 45dB
	Tuner : 45dB
	Tape : 45dB
	Adaptor : 45dB
	Phono : 40dB
Power Supply	100V, 50/60Hz (JM Model Only)
	120V, 60Hz (UL/UN Model Only)
	220V, 50Hz (AM Model Only)
Power Consumption	185W (JM Model Only)
	2.3A (UL/UN Model Only)
	3.5A (AM Model Only)
Semiconductors	7 IC's, 43 Transistors, 14 Zener Diodes, 10 FETs 33 Diodes, 2 Vacuum Tubes
Dimension	438 (W) ×148 (H) ×353 (D) mm
Weight	11.5Kg

NOTE: Due to continuing product improvement, specifications and design are subject to change without notice.

www.manualscenter.com

Parts Locations and Disassembly Instructions



Figure 1



Figure 2

www.manualscenter.com

1. Removal of Top Cover

(1) Remove six screws marked " ○ "as shown in Figures 3 and 4.

(2) Pull out the top cover in the direction of the arrow as shown in Figure 3.

1. 上蓋の外し方

(1) 6本のネジ（○印）を外します。(3、4図参照)

(2) 上蓋を矢印の方向に引き上げれば、上蓋は外れます。(3図参照)

2. Removal Front Panel

(1) Remove the volume control knob as shown in Figure 3.

(2) Remove three screws marked " ⊗"as shown in Figure 5.

(3) The Front Panel can be removed by pulling it forward.
But when the panel is engaged tightly, pull the panel end little by little, and the panel will be removed easily.

2. フロント・パネルの外し方

(1) ボリューム調整ツマミを外します。(3図参照)

(2) 3本のネジ（○印）を外します。(5図参照)

(3) 手前に引けばフロント・パネルは外せます。パネルがきつくはまっている場合は、少しずつ引きます。パネルは簡単に外せます。

3. Removal of Front Escutcheon

(1) After removal of The Front Panel, remove three control knobs (bass, treble, balance), remove two hooks (A), and remove six screws marked " ※ " as shown in Figures 3, 4 and 6.

(2) Discconnect all wires from the Front Escutcheon.

(3) The Front Escutcheon with Function LED, Tone and Headphone P. C. Boards can be removed completely.

3. フロント・エスカッションの外し方

(1) フロント・パネルを外してから、3個の調整ツマミ（バス、トレブル、バランス）、2箇所のフック（A）及び6本のネジ（※印）を外します。(3、4、6図参照)

(2) フロント・エスカッションから出ている全てのリード線を外します。

(3) 以上でフロント・エスカッションと一緒にファンクションLED基板、トーン及びヘッドホン基板は外れます。



Figure 3



Figure 4

4. Removal of Function LED P. C. Boord

(1) After removal of Front Escutcheon, remove four hooks (B) as shown in Figure 7.

4. ファンクションLED基板の外し方

(1) フロント・エスカッションを外してから、4箇所のフック(B)を外します。(7図参照)



Figure 5



Figure 6

5. Removal of Tone Control LED P. C. Board

(1) After removal of Front Escutcheon, remove two hooks (C) as shown in Figure 7.

5. トーン・コントロールLED基板の外し方

(1) フロント・エスカッションを外してから、2箇所のフック(C)を外します。(7図参照)

6. Removal of Headphone P. C. Board

(1) After removal of Front Escutcheon, remove two screws marked "◎" as shown in Figure 7.

6. ヘッドホーン基板の外し方

(1) フロント・エスカッションを外してから、2本のネジ（◎印）を外します。（7図参照）



Figure 7



Figure 8

7. Removal of Front Chassis

(1) After removal of Front Escutcheon, remove seven screws marked "☆" as shown in Figure 8.

(2) Remove Front Chassis upward and then proceed to items 7-1～7-10.

7. フロント・シャーシの外し方

(1) フロント・シャーシを外してから、7本のネジ（☆印）を外します。（8図参照）

(2) フロント・シャーシを上方に外します。続いて7－1から7－10に進みます。

7-1 Removal of Driver P. C. Board

(1) Remove two screws marked "◆" as shown in Figure 8.

(2) Disconnect all, wires from the Dirver P. C. Board.

7-1 ドライバー基板の外し方

(1) 2本のネジ（◆印）を外します。（8図参照）

(2) ドライバー基板から出ている全てのリード線を外します。

7-2 Removal of Transistor P. C. Board

(1) Remove a screw marked "✪" as shown in Figure 5.

(2) Disconnect all wires from the Transistor P. C. Board.

7-2 トランジスター基板の外し方

(1) 1本のネジ（✪印）を外します。（5図参照）

(2) トランジスター基板から出ている全てのリード線を外します。



Figure 9

7-3 Removal of AC P. C. Board

(1) Remove two knobs (a) and remove four screws marked "▲" as shown in Figure 6.
(2) Disconnect all wires from the AC P. C. Board.

7-3 AC基板の外し方

(1) 2個のツマミ (a) と4本のネジ (▲印) を外します。(6図参照)
(2) AC基板から出ている全てのリード線を外せば、基板は外せます。

7-4 Removal of Heat-UP Switch P. C. Board

(1) Remove one knob (b) and remove two screws marked "凸" as shown in Figure 6.
(2) Disconnect all wires from the Heat-up Switch P .C. Board.

7-4 ヒートアップ・スイッチ基板の外し方

(1) 1個のツマミ (b) と2本のネジ (凸印) を外します。(6図参照)
(2) ヒートアップ・スイッチ基板から出ている全てのリード線を外せば、基板は外せます。

7-5 Removal of Tube P. C. Board

(1) Remove two screws marked "◪" as shown in Figure 9.
(2) Remove one hook (D) as shown in Figure 6.
(3) Disconnect all wires from the Tube P. C. Board.

7-5チューブ基板の外し方

(1) 2本のネジ (◪印) を外します。(9図参照)
(2) 1箇所のフック (D) を外します。(6図参照)
(3) チューブ基板から出ている全てのリード線を外します。

7-6 Removal of REC P. C. Board

(1) Remove four screws marked "■" and remove nine knobs (C) as shown in Figure 6.
(2) Disconnect all wires from the REC P. C. Board.

7-6REC基板の外し方

(1) 4本のネジ (■印) と9個のツマミ (C) を外します。(6図参照)
(2) REC基板から出ている全てのリード線を外します。

7-7 Removal of Volume Control P. C. Board.

(1) Remove one nut (A) and one washer (A) as shown in Figure 8.
(2) Disconnect all wires from the Volume Control P. C. Board.

7-7 ボリューム・コントロール基板の外し方

(1) 1個のナット (A) とワッシヤー (A) を外します。(8図参照)
(2) ボリューム・コントロール基板から出ている全てのリード線を外します。



Figure 10



Figure 11



Figure 12

www.manualscenter.com

7-8 Removal of Tone Control P. C. Board

(1) Remove one knob (e) and six screws marked "◐" as shown in Figure 8.
(2) Remove two nuts (B) as shown in Figure 8.
(3) Disconnect all wires from the Tone Control P. C. Board.

7-8 トーン・コントロール基板の外し方

(1) 1個のツマミ (e) と6本のネジ (◐印) を外します。(8図参照)
(2) 2個のナット (B) を外します。(8図参照)
(3) トーン・コントロール基板から出ている全てのリード線を外せば基板は外せます。

7-9 Removal of Function P. C. Board and Balance P. C. Board

(1) Remove seven knobs (f) and remove five screws marked "●" as shown in Figure 5 and 8.
(2) Remove one nut (c) as shown in Figure 8.
(3) Remove a solder (a) as shown in Figure 5.
(4) Disconnect all wires from the Function P. C. Board and Balance P. C. Board.

7-9 ファンクション基板及びバランス基板の外し方

(1) 7個のツマミ (f) と5本のネジ (●印) を外します。(8図参照)
(2) 1個のナット (c) を外します。(8図参照)
(3) 1箇所の半田 (a) を外します。(5図参照)
(4) ファンクション基板とバランス基板から出ている全てのリード線を外します。

7-10 Removal of AV Front P. C. Boad.

(1) Remove one knob (d) and remove two screws marked "★" as shown in Figure 8.
(2) Disconnect all wires from the AV Front P. C. Board.

7-10 AVフロント基板の外し方

(1) 1個のツマミ (d) と2本のネジ (★印) を外します。(8図参照)
(2) AVフロント基板から出ている全てのリード線を外せば基板は外れます。

8. Removal of Equalizer P. C. Board.

(1) Remove six screws marked "⧗" as shown in Figures 10 and 11.
(2) Remove the Equalizer Hold Panel as shown in Figure 5.
(3) Disconnect all wires from the Equalizer P. C. Board.

8. イコライザー基板の外し方

(1) 6本のネジ (⧗印) を外します。(10、11図参照)
(2) イコライザー・ホールドパネルを外します。(5図参照)
(3) イコライザー基板から出ている全てのリード線を外します。

9. Removal of Rear Cover

(1) Remove twelve screws marked "△" as shown in Figure 10.
(2) Disconnect all wires from the AC Outlet, AV Monitor and ADP P. C. Boards.
(3) The rear cover with AV Monitor and ADP P. C. Boards can be removed completely.

9. 後面カバーの外し方

(1) 12本のネジ (△印) を外します。(10図参照)
(2) ACアウトレット基板、AVモニター基板及びADP基板を外します。
(3) 後面カバーと一緒にAVモニター基板及びADP基板が外れます。

10. Removal of AV Monitor P. C. Board

(1) Remove five screws marked "⊛" as shown in Figure 10.

10. AVモニター基板の外し方

(1) 5本のネジ (⊛印) を外せば、基板は外せます。(10図参照)

11. Removal of ADP P. C. Board

(1) Remove one screw marked "○" as shown in Figure 10.

11. ADP基板の外し方

(1) 1本のネジ (▲印) を外せば、基板は外れます。(10図参照)

12. Removal of Bottom Chassis

(1) Remove two screws marked "■" as shown in Figure 4.

12. 底面シャーシの外し方

(1) 2本のネジ (■印) を外せば底面シャーシは外せます。(4図参照)

13. Removal of Main P. C. Board

(1) Remove five screws marked "▣" and two solders (c) as show in Figures 5 and 12.
(2) Disconnect all wires from the Main P. C. Board.

13. メイン基板の外し方

(1) 5本のネジ (▣印) と2箇所の半田 (c) を外します。(5、12図参照)
(2) メイン基板から出ている全てのリード線を外せば、基板は外れます。

Adjustment Procedures

1. Connections



Figure 13

2. Control Settings

Power Switch ····· ON
Volume Control Knob ····· Minimum (fully counterclockwise)
Treble Control knob ····· Center Position
Bass Control knob ····· Center Position
Balance Control knob ····· Center Position
Others ····· OFF

3. Adjustment Procedures

(1) Idling Adjustment (Figure 13)
Adjust VR7301 (VR7302) until 65mV is obtained between T.P.1 (T.P.3) and T.P.2 (T.P.4).

Note : This adjustment should be made approx. 5 minutes after the power on.

調整方法

1. 接続図



<13図>

2. スイッチ類の位置

電源スイッチ ····· ON
ボリューム調整ツマミ ····· 最小 (反時計方向)
トレブル調整ツマミ ····· 中央
バス調整ツマミ ····· 中央
バランス調整ツマミ ····· 中央
その他 ····· OFF

3. 調整方法

(1) アイドリング調整 (13図参照)
テストポイント1 (3) と2 (4) の間が65mVになるまで、VR7301で調整します。

注： この調整は電源を入れてから最低5分後に行ないます。

Adjustment Locations



<Figure 14>
<14図>

Main P.C. Board
メイン基板

Block Diagram



www.manualscenter.com

Schematic Diagram



www.manualscenter.com



NOTES:

1. All resistance values are in ohms. K = 1,000
2. All capacitance values are in microfarads. P = $\frac{1}{1,000,000}$

	D	G	S
Q1117	30.5V	5.6V	6.3V
Q1118	-5.6V	-30.5V	-29.8V
Q2101	10.6V	0V	0.2V
Q2102	10.6V	0V	0.2V
Q7101-1	-12V	0V	-0.3V
Q7101-2	-12V	0V	-0.3V
Q7102-1	-12V	0V	-0.3V
Q7102-2	-12V	0V	-0.3V
Q7301	53.3V	2V	0V
Q7302	53.3V	2V	0V
Q7303	-53.3V	-2.4V	0V
Q7304	-53.3V	-2.4V	0V

	C	B	E
Q7103-1	-95V	-12.6V	-12V
Q7103-2	-95V	-12.6V	-12V
Q7104-1	-95V	-12.6V	-12V
Q7104-2	-95V	-12.6V	-12V
Q7105-1	-95V	-98.7V	-99.3V
Q7105-2	-98.7V	-98.7V	-99.3V
Q7106-1	-95V	-12.6V	-12V
Q7106-2	-98.7V	-98.7V	-99.3V
Q7107	30V	98.7V	99.3V
Q7108	30V	98.7V	99.3V
Q7109	-99.9V	-3V	-2.4V
Q7110	-99.9V	-3V	-2.4V
Q7305	2V	-1.8V	-2.4V
Q7306	2V	-1.8V	-2.4V
Q7307	2V	0V	0V
Q7308	2V	0V	0V
Q7309	-2.4V	0V	0V
Q7310	-2.4V	0V	0V
Q7311	53.3V	0V	0V
Q7312	53.3V	0V	0V

	C	B	E
Q1011	6.2V	7V	7.7V
Q1012	7.7V	6.2V	5.5V
Q1101	126V	100.5V	99.9V
Q1102	-126V	-100.5V	-99.9V
Q1103	0V	62.5V	63.1V
Q1104	0V	-62.5V	-63.1V
Q1105	62.5V	37.4V	36.8V
Q1106	-62.5V	-37.4V	-36.8V
Q1107	62.5V	37.4V	36.8V
Q1108	-62.5V	-37.4V	-36.8V
Q1109	30.5V	22.6V	22V
Q1110	-30.5V	-22.6V	-22V
Q1111	0V	16.3V	16.9V
Q1112	0V	-16.3V	-16.9V
Q1113	17V	5.6V	5V
Q1114	-17V	-5.6V	-5V
Q1115	16.9V	5.6V	5V
Q1116	-16.9V	-5.6V	-5V
Q3001	12.1V	5.8V	5.1V
Q3002	12.1V	5.8V	5.1V
Q3003 (AN-1)	0.1V (12.1V)	0.8V (0V)	0V (0V)
Q3004 (Front)	12.1V (0.1V)	0V (0.8V)	0V (0V)
Q5101	1.3V	0.3V	0V
Q5104	-0.7V	53.3V	53.3V
Q5105	0V	4.2V	3.6V

	P	G	K	P	G	K
Q4901	-3V	-95V	-92V	-3V	-95V	-92V
Q4902	-3V	-95V	-92V	-3V	-95V	-92V

IC1119	
1	12.1V
2	0V
3	16.2V

IC1120	
1	12.1V
2	0V
3	16.2V

IC2101	
1	0V
2	10.6V
3	10.6V
4	-22V
5	10.6V
6	10.6V
7	0V
8	22V

IC3001	
1	
2	12.1V
3	4.4V
4	12.1V
5	4.3V
6	
7	0V
8	
9	
10	
11	5V
12	5.8V
13	
14	4.4V
15	4.3V
16	4.4V

IC4001	
1	0V
2	0V
3	0V
4	-14.4V
5	0V
6	0V
7	0V
8	14.4V

IC4002	
1	0V
2	0V
3	0V
4	-14.3V
5	0V
6	0V
7	0V
8	13.9V

IC5101	
1	-0.7V
2	0V
3	0V
4	0V
5	-0.8V
6	-0.3V
7	0V
8	1.3V
9	3.1V

Measureing Condition

1. Power Supply Voltage
   AM model only : AC 220V
   UN/UL model only : AC 120V
   JM model only : AC100V
2. Measuring Meter
   Digital Voltmeter
3. Measuring Point Reference
   Between GND
4. Measuring Condition
   No signal input

LV-105 u

www.manualscenter.com

Parts Layout on P.C. Boards and Wiring Diagram (1/3)



NOTE:
Description on marks for symbol No.
● JM model only
▲ AM model only
■ UL model only
★ UN model only

www.manualscenter.com

am (1/3)



NOTE:
Description on marks for symbol No.
- ● JM model only
- ▲ AM model only
- ■ UL model only
- ★ UN model only

BLU	Blue
GRN	Green
BLK	Black
GRY	Gray
WHT	White
RED	Red
BRN	Brown
ORG	Orange
YEL	Yellow
VIO	Violet
PNK	Pink
GRN/WHT	Green/White
GRY/WHT	Gray/White
GRY/YEL	Gray/Yellow
GRN/YEL	Green/Yellow
SHLD	Shield

www.manualscenter.com

Parts Layout on P.C. Boards and Wiring Diagram (2/3)



www.manualscenter.com

agram (2/3)



NOTE:
Description on marks for symbol No.
● JM model only
▲ AM model only
■ UL model only
★ UN model only

BLU	Blue
GRN	Green
BLK	Black
GRY	Gray
WHT	White
RED	Red
BRN	Brown
ORG	Orange
YEL	Yellow
VIO	Violet
PNK	Pink
GRN/WHT	Green/White
GRY/WHT	Gray/White
GRY/YEL	Gray/Yellow
GRN/YEL	Green/Yellow
SHLD	Shield

www.manualscenter.com

Parts Layout on P.C. Boards and Wiring Diagram (3/3)



www.manualscenter.com

ram (3/3)



BLU	Blue
GRN	Green
BLK	Black
GRY	Gray
WHT	White
RED	Red
BRN	Brown
ORG	Orange
YEL	Yellow
VIO	Violet
PNK	Pink
GRN/WHT	Green/White
GRY/WHT	Gray/White
GRY/YEL	Gray/Yellow
GRN/YEL	Green/Yellow
SHLD	Shield

www.manualscenter.com

Electrical Parts List

Resistor : Carbon resistors under 1/4 watts are not mentioned in the parts list, please confirm them by schematic diagram.
uF = microfarads, pF = picofarads

Abbreviations

RES. = Resistor	CAP. = Capacitor
C.F. = Carbon Film	ELY. = Electrolytic
M.F. = Metal Film	CER. = Ceramic
M.O. = Metal Oxide Film	MYL. = Mylar
M.P. = Metal Plate	TAN. = Tantalum
TR. = Transistor	POLY. = Polystyrol
TRANS. = Transformer	PP. = Polypropylene
CP. = Chip	PLT. = Polyethylene

Symbol No.	Part No.	Description		
AC P. C. Board				
Switches				
● S1001	40T61963F02	Push SDU3P (Power)		
■ S1001	40T61963F02	Push SDU3P (Power)		
▲ S1001	40T68579F01	Push SDU3P (Power)		
★ S1001	40T61963F02	Push SDU3P (Power)		
S1002	40T67388F01	Push SUL231A (Speaker A, B)		
Capacitors				
C1001	08T57437F11	CER., 0.01 μ F		
● C1002	08T57437F11	CER., 0.01 μ F		
■ C1002	08T57437F11	CER., 0.01 μ F		
★ C1002	08T57437F11	CER., 0.01 μ F		
▲ C1003	08T57437F11	CER., 0.01 μ F		
Resistors				
▲ R7341	06T00007L52	M.O., 300 ohm 2W		
■ R7341	06T00007L52	M.O., 300 ohm 2W		
★ R7341	06T00007L52	M.O., 300 ohm 2W		
▲ R7342	06T00007L52	M.O., 300 ohm 2W		
■ R7342	06T00007L52	M.O., 300 ohm 2W		
★ R7342	06T00007L52	M.O., 300 ohm 2W		
Heat Up P. C. Board				
Transistor/Diodes				
Q1011	48T81102F01	TR., 2SA1015		
D1011	48T71195F01	1S1553		
D1012	48T71195F01	1S1553		
ZD1011	48T52739F31	Zener HZ5C-1		

Symbol No.	Part No.	Description		
Switches				
● S1011	40T81345F01	Power SDS2.5 (Pre-Heating)		
▲ S1011	40T81345F01	Power SDS2.5 (Pre-Heating)		
■ S1011	40T83288F01	Push SDDSA-3 (Pre-Heating)		
★ S1011	40T92612F01	Push SDDFA3 (Pre-Heating)		
Equalizer P. C. Board				
IC/Transistors				
IC2101	51T00038L01	M5220P		
Q1109	48T64376F01	TR., 2SC3423		
Q1110	48T64375F01	TR., 2SA1360		
Q1111	48T81102F01	TR., 2SA1015		
Q1112	48T81101F01	TR., 2SC1815		
Q1113	48T81101F01	TR., 2SC1815		
Q1114	48T81102F01	TR., 2SA1015		
Q1115	48T81101F01	TR., 2SC1815		
Q1116	48T81102F01	TR., 2SA1015		
Q1117	48T52152F01	FET, 2SK30A		
Q1118	48T52152F01	FET, 2SK30A		
Q1501	48T81101F01	TR., 2SC1815		
Q1502	48T81101F01	TR., 2SC1815		
Q2101	48T72887F02	FET, 2SK332		
Q2102	48T72887F02	FET, 2SK332		
Diodes				
D1501	48S40477U01	IN4003		
D1502	48T71195F01	1S1553		
D1503	48S40477U01	IN4003		
ZD1105	48T52741F03	Zener HZ6A-3L		
ZD1106	48T52741F03	Zener HZ6A-3L		
ZD1107	48T52741F03	Zener HZ6A-3L		
ZD1108	48T52741F03	Zener HZ6A-3L		
ZD1110	48T52741F51	Zener HZ16-3L		
ZD1111	48T52741F51	Zener HZ16-3L		

Notes : ● : For Japanese model only (JM), ▲ : For European model only (AM),
■ : For North American model only (UL), ★ : For Canadian model only (UN), Others : Common.

	Symbol No.	Part No.	Description
	Inductors		
▲	L2101	24T83130F02	33 μ H
▲	L2102	24T83130F02	33 μ H
▲	L2103	24T83130F02	33 μ H
▲	L2104	24T83130F02	33 μ H
	Relays		
	RL1501	80T72831F01	G6A-434P-12VDC
●	RL1502	80T00048L01	RZ-12W
■	RL1502	80T83717F02	DS2Y-S-DC12V
▲	RL1502	80T83717F02	DS2Y-S-DC12V
★	RL1502	80T83717F02	DS2Y-S-DC12V
	Jacks		
	J2101-1, J2101-2	09T81363F01	Plate, Phone (Phono)
	J2102-1, J2102-6	09T81364F01	Plate, Phone (CD, Tuner)
	J2103-1, J2103-6	09T81364F01	Plate, Phone (Tape1, Tape2)
	Capacitors		
	C1105	23T00154L33	ELY., 10 μ F/50V
	C1106	23T00154L33	ELY., 10 μ F/50V
	C1107	23T00132L25	ELY., 47 μ F/50V
	C1108	23T00132L25	ELY., 47 μ F/50V
	C1112	23T00154L33	ELY., 10 μ F/50V
	C1113	23T00154L33	ELY., 10 μ F/50V
	C1114	08T57851F21	TF., 0.47 μ F
▲	C1115	08T81196F34	Mica, 100pF
▲	C1116	08T81196F34	Mica, 100pF
●	C1501	23T00138L22	ELY., 220 μ F/16V
★	C1501	23T00138L21	ELY., 100 μ F/16V
▲	C1501	23T00138L21	ELY., 100 μ F/16V
■	C1501	23T00138L21	ELY., 100 μ F/16V
	C1502	23T00138L24	ELY., 470 μ F/16V
	C1503	23T00138L19	ELY., 33 μ F/16V
	C2101	08T61630F73	POLY., 100pF
	C2102	08T61630F73	POLY., 100pF
▲	C2103	08T61630F26	POLY., 220pF
▲	C2104	08T61630F26	POLY., 220pF
	C2107	08T00015L19	PP., 3300pF
	C2108	08T00015L19	PP., 3300pF
▲	C2109	21S40655F20	CER., 56pF
▲	C2110	21S40655F20	CER., 56pF
	C2111	23T00153L01	ELY., (B.P.) 1000 μ F/6.3V
	C2112	23T00153L01	ELY., (B.P.) 1000 μ F/6.3V
	C2113	08T00015L38	PP., 9100pF
	C2114	08T00015L38	PP., 9100pF
	C2115	08T71458F39	PP., 0.0318 μ F
	C2116	08T71458F39	PP., 0.0318 μ F
	C2117	23T61177F06	ELY., (B.P.) 4.7 μ F/100V
	C2118	23T61177F06	ELY., (B.P.) 4.7 μ F/100V
▲	C2119	08T00015L18	PP., 2700pF
▲	C2120	08T00015L18	PP., 2700pF
▲	C2501	08T61630F34	POLY., 470pF
▲	C2502	08T61630F34	POLY., 470pF
▲	C2503	08S40805F05	CER., 470pF
▲	C2504	08S40805F05	CER., 470pF
▲	C2505	08S40805F05	CER., 470pF
▲	C2506	08S40805F05	CER., 470pF
▲	C2507	08S40805F05	CER., 470pF
▲	C2508	08S40805F05	CER., 470pF
▲	C2511	08S40805F05	CER., 470pF
▲	C2512	08S40805F05	CER., 470pF
▲	C2521	08T57851F24	TF., 1000pF
●	C2521	08T57851F21	TF., 0.47 μ F
■	C2521	08T57851F21	TF., 0.47 μ F
★	C2521	08T57851F21	TF., 0.47 μ F
	C2522	08T57851F21	TF., 0.47 μ F
	C2523	08T57851F21	TF., 0.47 μ F
	Resistors		
	R2133	06T00147L57	C.F., 470 ohm 1/2W
	R2134	06T00147L57	C.F., 470 ohm 1/2W
	R2501	06T00147L41	C.F., 100 ohm 1/2W
	R2502	06T00147L41	C.F., 100 ohm 1/2W
	Driver P. C. Board		
	Transistors		
	Q1101	48T62642F01	2SC2336
	Q1102	48T62641F01	2SA1006
	Q1103	48T64375F01	2SA1360
	Q1104	48T64376F01	2SC3423
	Q1105	48T64376F01	2SC3423

Notes : ● : For Japanese model only (JM), ▲ : For European model only (AH),
■ : For North American model only (UL), ★ : For Canadian model only (UN), Others : Common.

www.manualscenter.com

Symbol No.	Part No.	Description
Q1106	48T64375F01	2SA1360
Q1107	48T64376F01	2SC3423
Q1108	48T64375F01	2SA1360
Q7101	48T62284F02	FET, 2SJ75
Q7102	48T62284F02	FET, 2SJ75
Q7103	48T72597F01	2SA995
Q7104	48T72597F01	2SA995
Q7105	48T72598F01	2SC2291
Q7106	48T72598F01	2SC2291
Q7107	48T64375F01	2SA1360
Q7108	48T64375F01	2SA1360
Q7109	48T71448F01	2SA1361
Q7110	48T71448F01	2SA1361
Diodes/LEDs		
LD7101	48T52953F03	LED BR5507S (RED)
LD7102	48T52953F03	LED BR5507S (RED)
ZD1101	48T52741F74	Zener HZ36-2L
ZD1102	48T52741F74	Zener HZ36-2L
ZD1103	48T52741F74	Zener HZ36-2L
ZD1104	48T52741F74	Zener HZ36-2L
ZD7101	48T52741F38	Zener HZ12A-2L
ZD7102	48T52741F38	Zener HZ12A-2L
Capacitors		
C1101	23T00154L33	ELY., 10 μ F/50V
C1102	23T00154L33	ELY., 10 μ F/50V
C1103	23T00138L86	ELY., 10 μ F/160V
C1104	23T00138L86	ELY., 10 μ F/160V
▲ C1151	08T81196F42	Mica, 220pF
● C7101	08T00125L04	POLY., 100pF
■ C7101	08T00125L04	POLY., 100pF
★ C7101	08T00125L04	POLY., 100pF
● C7102	08T00125L04	POLY., 100pF
■ C7102	08T00125L04	POLY., 100pF
★ C7102	08T00125L04	POLY., 100pF
▲ C7105	08T61642F12	Mica, 22pF
▲ C7106	08T61642F12	Mica, 22pF
C7107	23T61177F06	ELY., (B.P.) 4.7 μ F/100V
C7108	23T61177F06	ELY., (B.P.) 4.7 μ F/100V
C7109	23T00154L12	ELY., 47 μ F/16V
C7110	23T00154L12	ELY., 47 μ F/16V
C7113	23T00138L85	ELY., 4.7 μ F/160V
C7114	23T00138L85	ELY., 4.7 μ F/160V
C7115	23T00138L85	ELY., 4.7 μ F/160V
C7116	23T00138L85	ELY., 4.7 μ F/160V
▲ C7117	08T61630F22	POLY., 150pF
▲ C7118	08T61630F22	POLY., 150pF
Resistors : (All resistors are carbon film 1/2W±5% unless otherwise noted.)		
R7101	06T00147L49	220 ohm
R7102	06T00147L49	220 ohm
R7103	06T00148L20	180K ohm
R7104	06T00148L20	180K ohm
R7105	06T00147L41	100 ohm
R7106	06T00147L41	100 ohm
R7107	06T00147L95	18K ohm
R7108	06T00147L95	18K ohm
R7109	06T00148L50	3.3M ohm
R7110	06T00148L50	3.3M ohm
R7153	06T69013F41	Fuse 100 ohm 1/4W
R7154	06T69013F41	Fuse 100 ohm 1/4W
Main P. C. Board		
IC's		
IC1119	51T72375F01	NJM78M12A
IC1120	51T72375F01	NJM78M12A
IC5101	51T67437F01	TA7317P
Transistors		
Q5104	48T52545F02	2SA970
Q5105	48T81102F01	2SA1015
Q7307	48T53301F02	2SC2240
Q7308	48T53301F02	2SC2240
Q7309	48T52545F02	2SA970
Q7310	48T52545F02	2SA970
Q7311	48T53301F02	2SC2240
Q7312	48T53301F02	2SC2240
Diodes		
D1201	48S40477U07	IN4007
D1202	48S40477U07	IN4007
D1203	48S40477U07	IN4007
D1204	48S40477U07	IN4007
D1205	48S40477U01	IN4003

Notes : ● : For Japanese model only (JM), ▲ : For European model only (AM),
■ : For North American model only (UL), ★ : For Canadian model only (UN), Others : Common.

Symbol No.	Part No.	Description		
D1206	48S40477U01	IN4003		
D1207	48S40477U01	IN4003		
D1208	48S40477U01	IN4003		
D1211	48S40477U01	IN4003		
D1212	48S40477U01	IN4003		
D5102	48S40477U01	IN4003		
D7301	48T71195F01	1S1553		
D7302	48T71195F01	1S1553		
D7303	48T71195F01	1S1553		
D7304	48T71195F01	1S1553		
D7305	48T71195F01	1S1553		
D7306	48T71195F01	1S1553		
D7307	48T71195F01	1S1553		
D7308	48T71195F01	1S1553		
D7309	48T73079F02	ISS82		
D7310	48T73079F02	ISS82		
D7311	48T73079F02	ISS82		
D7312	48T73079F02	ISS82		
ZD5101	48T52739F31	Zener HZ5C-1		
BD1213	48T67435F01	Bridge, D5FD20		
BD1209	48T71451F01	Bridge, KBL-02		
BD1210	48T61415F03	Bridge, 1G4B41		
Coils/Relay				
L7301	24T74614F01	Inductor 1.1 μ H		
L7302	24T74614F01	Inductor 1.1 μ H		
RL5101	80T53350F01	Relay, G2Z-222P-US		
Jacks				
J7301	09T81893F02	Terminal SP T5957L		
J7302	09T81893F01	Terminal SP T5957		
Capacitors				
● C1110	23T00136L33	ELY., 1000 μ F/16V		
▲ C1110	23T00137L49	ELY., 1000 μ F/16V		
■ C1110	23T00137L49	ELY., 1000 μ F/16V		
★ C1110	23T00137L49	ELY., 1000 μ F/16V		
C1111	23T00138L24	ELY., 470 μ F/16V		
● C1201	23T00142L36	ELY., 220 μ F/160V		
▲ C1201	23T00142L40	ELY., 220 μ F/160V		
■ C1201	23T00142L40	ELY., 220 μ F/160V		
★ C1201	23T00142L40	ELY., 220 μ F/160V		
● C1202	23T00142L36	ELY., 220 μ F/160V		

Symbol No.	Part No.	Description		
▲ C1202	23T00142L40	ELY., 220 μ F/160V		
■ C1202	23T00142L40	ELY., 220 μ F/160V		
★ C1202	23T00142L40	ELY., 220 μ F/160V		
● C1203	23T00142L17	ELY., 3300 μ F/35V		
▲ C1203	23T00142L39	ELY., 3300 μ F/35V		
■ C1203	23T00142L39	ELY., 3300 μ F/35V		
★ C1203	23T00142L39	ELY., 3300 μ F/35V		
● C1204	23T00142L17	ELY., 3300 μ F/35V		
▲ C1204	23T00142L39	ELY., 3300 μ F/35V		
■ C1204	23T00142L39	ELY., 3300 μ F/35V		
★ C1204	23T00142L39	ELY., 3300 μ F/35V		
C1205	23T00022L05	ELY., 8200 μ F/71V		
C1206	23T00022L05	ELY., 8200 μ F/71V		
C1207	23T00022L05	ELY., 8200 μ F/71V		
C1208	23T00022L05	ELY., 8200 μ F/71V		
C1209	23T00138L72	ELY., 1 μ F/100V		
● C1210	23T00142L08	ELY., 6800 μ F/16V		
▲ C1210	23T00142L38	ELY., 6800 μ F/16V		
■ C1210	23T00142L38	ELY., 6800 μ F/16V		
★ C1210	23T00142L38	ELY., 6800 μ F/16V		
● C1211	23T00137L44	ELY., 3300 μ F/25V		
▲ C1211	23T00137L48	ELY., 3300 μ F/25V		
■ C1211	23T00137L48	ELY., 3300 μ F/25V		
★ C1211	23T00137L48	ELY., 3300 μ F/25V		
C5101	23T00140L25	ELY., (B.P.) 33 μ F/25V		
C5102	23T00140L25	ELY., (B.P.) 33 μ F/25V		
C5103	23T00138L71	ELY., 0.47 μ F/100V		
C5104	23T00138L18	ELY., 22 μ F/16V		
C5105	23T00138L18	ELY., 22 μ F/16V		
C5106	23T00138L11	ELY., 47 μ F/10V		
C7301	08T00015L17	PP., 2200pF		
C7302	08T00015L17	PP., 2200pF		
C7303	08T00015L17	PP., 2200pF		
C7304	08T00015L17	PP., 2200pF		
C7305	08T00015L29	PP., 0.022 μ F		
C7306	08T00015L29	PP., 0.022 μ F		
▲ C7351	08T57851F24	TF., 1000pF		
▲ C7352	08T57851F24	TF., 1000pF		
▲ C7353	08T57851F24	TF., 1000pF		
▲ C7354	08T57851F24	TF., 1000pF		
▲ C7355	08T57851F24	TF., 1000pF		
▲ C7356	08T57851F24	TF., 1000pF		
▲ C7357	08T50579F26	TF., 1000pF		
▲ C7358	08T50579F26	TF., 1000pF		
▲ C7359	08T50579F26	TF., 1000pF		
▲ C7360	08T50579F26	TF., 1000pF		

Notes : ● : For Japanese model only (JM), ▲ : For European model only (AM),
■ : For North American model only (UL), ★ : For Canadian model only (UN), Others : Common.

Symbol No.	Part No.	Description
Resistors		
R7305	06T69013F41	Fuse 100 ohm 1/4W
R7306	06T69013F41	Fuse 100 ohm 1/4W
R7307	06T69013F41	Fuse 100 ohm 1/4W
R7308	06T69013F41	Fuse 100 ohm 1/4W
R7317	06T67397F01	M.P 0.22 ohm
R7318	06T67397F01	M.P 0.22 ohm
R7321	06T00007L29	M.O., 33 ohm 2W
R7322	06T00007L29	M.O., 33 ohm 2W
R7323	06T00005L17	M.O., 10 ohm 1W
R7324	06T00005L17	M.O., 10 ohm 1W
VR7301	18B44064J01	Variable, 470 ohm B 1/2W
VR7302	18B44064J01	Variable, 470 ohm B 1/2W
AV Monitor P. C. Board		
IC/Transistors		
IC3001	51T80995F01	M51320P
Q3001	48T81101F01	TR., 2SC1815
Q3002	48T81101F01	TR., 2SC1815
Q3003	48T81101F01	TR., 2SC1815
● Q3004	48T81101F01	TR., 2SC1815
▲ Q3004	48S43525F05	TR., 2SC1815
■ Q3004	48S43525F05	TR., 2SC1815
★ Q3004	48S43525F05	TR., 2SC1815
Diodes/Relays		
D3001	48T71195F01	1S1553
D3002	48T71195F01	1S1553
RL3001	80T73804F02	Relay, FBR42NG012-P
RL3002	80T82335F01	Relay, G2E-1645A
Jacks		
J3001	09T81368F01	Plate, Phone (AV1, AV2)
J3002	09T81367F01	Plate, Phone (AV1, AV2)
J3003	09T81370F01	Plate, Phone (MONITOR)

Symbol No.	Part No.	Description
Capacitors		
C3001	23S57007F15	ELY., 47 μ F/16V
C3002	23S57007F15	ELY., 47 μ F/16V
C3003	23S57007F09	ELY., 10 μ F/16V
C3004	23S40657F62	ELY., 470 μ F/16V
C3005	23S40657F62	ELY., 470 μ F/16V
C3006	23S40657F62	ELY., 470 μ F/16V
▲ C3009	08S40805F05	CER., 470pF
▲ C3010	08S40805F05	CER., 470pF
▲ C3013	08S40805F05	CER., 470pF
▲ C3014	08S40805F05	CER., 470pF
C3019	23S57007F09	ELY., 10 μ F/16V
C3023	23S40657F62	ELY., 470 μ F/16V
Tone Control P. C. Board		
IC's/Switch		
IC4101	51T80136F01	M5238P
IC4102	51T52383F01	NJM4558D
S4101	40T81347F01	Switch, Push SUL122A (Tone In)
Capacitors		
C4101	08T57851F12	TF., 0.082 μ F
C4102	08T57851F12	TF., 0.082 μ F
C4103	08T52448F29	P.P., 4700pF
C4104	08T52448F29	P.P., 4700pF
C4105	23T00140L37	ELY., (B.P.) 2.2 μ F/50V
C4106	23T00140L37	ELY., (B.P.) 2.2 μ F/50V
C4107	08T52448F35	PP., 8200pF
C4108	08T52448F35	PP., 8200pF
▲ C4109	08T61642F27	Mica, 100pF
▲ C4110	08T61642F27	Mica, 100pF
C4501	23T00138L26	ELY., 4.7 μ F/25V
C4502	23T00138L26	ELY., 4.7 μ F/25V
C4503	23T00138L26	ELY., 4.7 μ F/25V
C4504	23T00138L26	ELY., 4.7 μ F/25V
C4505	08T57851F21	TF., 0.47 μ F
Volumes		
VR4101	18T67394F01	Control, 10KB×2 (BASS)
VR4102	18T67394F01	Control, 10KB×2 (TREBLE)

Notes : ● : For Japanese model only (JM), ▲ : For European model only (AM),
■ : For North American model only (UL), ★ : For Canadian model only (UN), Others : Common.

www.manualscenter.com

Symbol No.	Part No.	Description		
Function LED P. C. Board				
LED's				
LD6501	48T60947F04	SLH-34MG3F (GRN)		
LD6502	48T60947F04	SLH-34MG3F (GRN)		
LD6504	48T60947F05	SLH-34VR3F (RED)		
LD6506	48T60947F05	SLH-34VR3F (RED)		
LD6507	48T60947F04	SLH-34MG3F (GRN)		
LD6509	48T60947F04	SLH-34MG3F (GRN)		
LD6510	48T60947F04	SLH-34MG3F (GRN)		
LD6512	48T60947F04	SLH-34MG3F (GRN)		
LD6513	48T60947F04	SLH-34MG3F (GRN)		
LD6515	48T60947F04	SLH-34MG3F (GRN)		
LD6516	48T60947F04	SLH-34MG3F (GRN)		
LD6517	48T60947F04	SLH-34MG3F (GRN)		
LD6519	48T60947F04	SLH-34MG3F (GRN)		
LD6521	48T60947F04	SLH-34MG3F (GRN)		
LD6522	48T60947F05	SLH-34VR3F (RED)		
LD6523	48T60947F05	SLH-34VR3F (RED)		
AV Front P. C. Board				
Switch/Jacks				
S6007	40T81346F01	Switch, Push SUL121A (AV-2)		
J9501	09T67396F01	Plate, Phone (AV2, L)		
J9502	09T67396F01	Plate, Phone (AV2, R)		
J9503	09T67396F01	Plate, Phone (AV2, V)		
Capacitors				
C6202	23T00138L49	ELY., 10 μ F/50V		
▲ C9501	08S40805F05	CER., 470pF		
▲ C9502	08S40805F05	CER., 470pF		
C9505	08T57851F21	TF., 0.47 μ F		
C9506	08T57851F21	TF., 0.47 μ F		

Symbol No.	Part No.	Description		
Function P. C. Board				
Switches				
S6001-1 ~ S6001-7	40T81348F01	Push SUL702A (Monitor-1, 2, AV-1, 2 CD, Tuner, Phono)		
Rec P. C. Board				
Switches				
S6002-1 ~ S6002-2	40T82248F01	Push Spec 2 (CD Straight, Cartrige)		
S6003-1 ~ S6003-6	40T81349F01	Push Spec (Source, Tape2→1, AV2→1 Mode, Loud, Signal Prossesor)		
Capacitors				
C6001	08T52448F11	PP., 820pF		
C6002	08T52448F11	PP., 820pF		
● C6003	08T52448F41	PP., 0.015 μ F		
■ C6003	08T57851F03	TF., 0.015 μ F		
▲ C6003	08T57851F03	TF., 0.015 μ F		
★ C6003	08T57851F03	TF., 0.015 μ F		
● C6004	08T52448F41	PP., 0.015 μ F		
■ C6004	08T57851F03	TF., 0.015 μ F		
▲ C6004	08T57851F03	TF., 0.015 μ F		
★ C6004	08T57851F03	TF., 0.015 μ F		
Tube P. C. Board				
Capacitors				
C7151	08T81196F03	Mica, 3pF		
C7152	08T81196F03	Mica, 3pF		
C7153	08T81196F03	Mica, 3pF		
C7154	08T81196F03	Mica, 3pF		

Notes : ●: For Japanese model only (JM), ▲: For European model only (AM),
■: For North American model only (UL), ★: For Canadian model only (UN), Others : Common.

Symbol No.	Part No.	Description		
		ADP P. C. Board		
		Jack/Capacitors		
J9001	09T81365F01	Jack, Plate, Phone (SIGNAL PROCESSOR)		
▲ C9001	08S40805F05	CER., 470pF		
▲ C9002	08S40805F05	CER., 470pF		
C9007	08T57851F21	TF., 0.47 μ F		
C9008	08T57851F21	TF., 0.47 μ F		
		Miscellaneous		
● C1	08T57437F11	CAP., CER., 0.01 μ F		
■ C1	08T57437F11	CAP., CER., 0.01 μ F		
★ C1	08T57437F11	CAP., CER., 0.01 μ F		
▲ F1001	65T42077U22	Fuse Semko T4A		
● F1001	65T55050F19	Fuse NR608A-125V		
■ F1001	65T65292F03	Fuse GGL8A-250V		
★ F1001	65T65292F03	Fuse GGL8A-250V		
▲ F1301	65T42077U08	Fuse, Semko T-160mA		
■ F1301	65T66926F14	Fuse 51NM 1.25A-125V		
★ F1301	65T42077U08	Fuse Semko T-160mA		
▲ F1302	65T42077U08	Fuse Semko T-160mA		
■ F1302	65T66926F14	Fuse 51NM 1.25A-125V		
★ F1302	65T42077U08	Fuse Semko T-160mA		
▲ F1303	65T42077U08	Fuse Semko T-160mA		
■ F1303	65T66926F15	Fuse 51NM 1.6A-125V		
★ F1303	65T42077U08	Fuse Semko T-160mA		
▲ F1304	65T42077U08	Fuse Semko T-160mA		
■ F1304	65T66926F15	Fuse 51NM 1.6A-125V		
★ F1304	65T42077U08	Fuse Semko T-160mA		
▲ F1305	65T42077U15	Fuse Semko T-800mA		
■ F1305	65T66926F15	Fuse 51NM 1.6A-125V		
★ F1305	65T42077U15	Fuse Semko T-800mA		
▲ F1306	65T42077U20	Fuse Semko T-2.5A		
■ F1306	65T66926F18	Fuse 51NM 3.15A-125V		
★ F1306	65T42077U20	Fuse Semko T-2.5A		

Symbol No.	Part No.	Description		
● J1001	09T67405F02	Outlet AC		
■ J1001	09T67405F02	Outlet AC		
★ J1001	09T67405F02	Outlet AC		
● J1002	09T67405F02	Outlet AC		
▲ J1003	09T51831F01	Socket, Switch M-1615		
J8101	09T66672F01	Jack Headphone		
LD9601	48T60947F05	LED, SLH-34VR3F (RED)		
LD9602	48T60947F05	LED, SLH-34VR3F (RED)		
▲ P1001	28T43812P05	AC Power Cord		
● P1001	28T67434F01	AC Power Cord		
■ P1001	28T55335F02	AC Power Cord		
★ P1001	28T55335F02	AC Power Cord		
▲ P1002	09T51830F01	Plug Switch P-2120		
Q1012	48T56031F01	TR., 2SD1266		
■ Q4901	65T00091L01	Vacuum Tube 6CG7		
● Q4901	65T00091L03	Vacuum Tube 6CG7GE		
▲ Q4901	65T00091L01	Vacuum Tube 6CG7		
★ Q4901	65T00091L01	Vacuum Tube 6CG7		
■ Q4902	65T00091L01	Vacuum Tube 6CG7		
● Q4902	65T00091L03	Vacuum Tube 6CG7GE		
▲ Q4902	65T00091L01	Vacuum Tube 6CG7		
★ Q4902	65T00091L01	Vacuum Tube 6CG7		
Q5101	48T53301F02	TR., 2SC2240		
Q7301	48T67399F03	FET, 2SK405		
Q7302	48T67399F03	FET, 2SK405		
Q7303	48T67398F03	FET, 2SJ115		
Q7304	48T67398F03	FET, 2SJ115		
Q7305	48T64376F01	TR., 2SC3423		
Q7306	48T64376F01	TR., 2SC3423		
▲ T1001	25T81356F02	Trans., Power		
● T1001	25T81356F01	Trans., Power		
■ T1001	25T81356F03	Trans., Power		
★ T1001	25T81356F03	Trans., Power		
VR6001-1, VR6001-2	18T82249F01	Volume, Control 250K ohm (Balance)		
VR6002-1, VR6002-2	18T71727F02	Volume, Control 150K ohm×2		

Notes : ● : For Japanese model only (JM), ▲ : For European model only (AM),
■ : For North American model only (UL), ★ : For Canadian model only (UN), Others : Common.

www.manualscenter.com

Cabinet Assembly Parts List

Note : Parts without part number are not supplied.

	Symbol No.	Index	Part No.	Description		
	1	5-A	01B81332F01	Assy., Escutcheon Knob		
	3	1-A	15D67323F01	Cover, Top		
●	7	2-H	15C81265F01	Cover, Rear		
■	7	2-H	15C81265F05	Cover, Rear		
▲	7	2-H	15C81265F03	Cover, Rear		
★	7	2-H	15C81265F07	Cover, Rear		
	8	3-B	36A67330F01	Knob, Power		
	9	3-B	36A67331F01	Knob, Push (SP)		
	10	4-C	36A81266F01	Knob, Push		
	11		36A67333F01	Knob, Push		
	12	4-C	36A67334F01	Knob, Push (AV)		
	13	4-A	36B67336F01	Knob, Main Volume		
	14	6-A	36A67337F01	Knob, Tone Volume		
	15	4-C	43A67342F01	Spaser, Switch		
	16		07A81270F01	Bracket., Volt		
	17	3-H	07R51146F01	Support, TR		
	18	1-H	29T66964F01	Terminal, GND		
	19	1-G	43B41625J02	Support, Cord		
●	20	2-F	43T53136F01	Bush, Cap.		
■	20	2-F	43T53136F01	Bush, Cap.		
★	20	2-F	43T53136F01	Bush, Cap.		
	21		29A41814G01	Lug		
	22		03D40014G04	Screw, W/ Washer (M3×6)		
	23		03C40121T17	Screw, W/ Double Washer (M3×8)		
	24		07C67319F01	Frame, Tube		
	25		29C41045P05	Lug, Wrap 54mm		
●	26		54B62266F36	Label, Fuse 8A-125V		
■	26		54B62266F53	Label, Fuse		
▲	26		54B62266F54	Label, Fuse		
★	26		54B62266F53	Label, Fuse		
	27	3-E	47A82105F01	Shaft, PCB		
	28	4-C	15A69033F01	Guide, Volume		
	29	3-F	75A67341F01	Cushion, Tube		
●	31	3-C	09T51960F01	Holder, Fuse		
■	31	3-C	09T51960F01	Holder, Fuse		
★	31	3-C	09T51960F01	Holder, Fuse		
	32		29C41045P06	Lug, Board-In 50mm		
	33	4-H	75A82703F01	Cushion, Rubber		
	34	4-D	14S58462F12	Insulator, Cover		
	35		75A67063F03	Trann-Leg		

	Symbol No.	Index	Part No.	Description		
	36		75A67064F01	Felt		
	37		03S44205G28	Screw, Bind (M4×16)		
	38		03A82468F01	Screw, Bind (M3×10)		
	39		03S40018G08	Screw, Tapping (M3×8)		
	40		03S71031F04	Screw, Bind (M3×8)		
	41		03S40036U01	Screw, W/ Washer (M4×8)		
	42	3-A	04S40070G23	Washer, Flat (M3.3)		
	43	2-E	75A82303F01	Cushion, Rubber		
	45	6-A	03S40012G98	Screw, Countersink (M3×8)		
	46	3-G	03C40121T18	Screw, W/Double Washer (M3×10)		
	47	3-A	03S71031F05	Screw, Countersink (M3×8)		
	48	2-A	75S72374F70	Cushion, Rubber		
	49	5-B	07B67320F01	Frame, LED		
	50	5-A	14S58462F59	Insulator, Cover		
	51	3-F	09T64527F02	Socket, Tube 9Pin		
	52		14S81481F12	Insulator, Cover		
	53		41A68570F01	Spring, Volume		
	54	2-H	28T51067F01	Plug, Short Phono		
	55	5-B	01V81600F19	Assy., Function LED P.C.B		
●	68	4-A	01V81600F58	Assy., Front Panel		
■	68	4-A	01V83600F76	Assy., Front Panel		
▲	68	4-A	01V83600F76	Assy., Front Panel		
★	68	4-A	01V83600F76	Assy., Front Panel		
	70	3-E	47A81445F01	Shaft, Panel		
	79	4-E	84D81371F13	Assy., Balance P. C. Board		
	80	4-E	84D81371F09	Panel, AV Front Hold		
■	81	4-E	54B62266F49	Label, Fuse		
■	82		54B62266F50	Label, Fuse		
■	83	4-F	54B62266F51	Label, Fuse		
▲	84		09T45548F01	Holder, Fuse		
★	84	3-C	09T45548F01	Holder, Fuse		
■	84		09T45548F01	Holder, Fuse		
▲	85	3-F	14A83125F01	Insulator SP Terminal "B"		

Notes : ● : For Japanese model only (JM), ▲ : For European model only (AM),
■ : For North American model only (UL), ★ : For Canadian model only (UN), Others : Common.

Exploded View (Cabinet)



● : For Japanese model only (JM)
▲ : For European model only (AM)
■ : For North American model only (UL)
★ : For Canadian model only (UN)
Others : Common

www.manualscenter.com

Packing Assembly Parts List

Symbol No.	Part No.	Description		
● 101-1	68P80130F59	Owners, Manual 103JM		
▲ 101-1	68P81707F59	Owners, Manual 103AM		
■ 101-1	68P81707F58	Owners, Manual 103UR		
★ 101-1	68P81707F59	Owners, Manual		
102	56D67465F01	Packing, Tray		
● 103	56S71001F74	Carton, Packing		

Symbol No.	Part No.	Description		
▲ 103	56S71001F90	Carton, Packing		
■ 103	56S71001F90	Carton, Packing		
★ 103	56S71001F90	Carton, Packing		
104	56B40442T17	Packing, Front Frame		
105	56B40230G08	Sack, Polyethylene		
106	56A82796F01	Pad, Cushion		

Notes : ● : For Japanese model only (JM), ▲ : For European model only (AM),
■ : For North American model only (UL), ★ : For Canadian model only (UN), Others : Common.

Packing Method View



Parts List by the Destination

Symbol No.	Description	POWER SOURCE			
		JM● 100V Japanese	UL■ 120V North American	AM▲ 220V European	UN★ 120V Canadian
C1	Capacitor	08T57437F11	08T57437F11	Not Used	08T57437F11
C1002	Capacitor	08T57437F11	08T57437F11	Not Used	08T57437F11
C1003	Capacitor	Not Used	Not Used	08T57437F11	Not Used
C1110	Capacitor	23T00136L33	23T00137L49	23T00137L49	23T00137L49
C1115	Capacitor	Not Used	Not Used	08T81196F34	Not Used
C1116	Capacitor	Not Used	Not Used	08T81196F34	Not Used
C1151	Capacitor	Not Used	Not Used	08T81196F42	Not Used
C1201	Capacitor	23T00142L36	23T00142L40	23T00142L40	23T00142L40
C1202	Capacitor	23T00142L36	23T00142L40	23T00142L40	23T00142L40
C1203	Capacitor	23T00142L17	23T00142L39	23T00142L39	23T00142L39
C1204	Capacitor	23T00142L17	23T00142L39	23T00142L39	23T00142L39
C1210	Capacitor	23T00142L08	23T00142L38	23T00142L38	23T00142L38
C1211	Capacitor	23T00137L44	23T00137L48	23T00137L48	23T00137L48
C1501	Capacitor	23T00138L22	23T00138L21	23T00138L21	23T00138L21
C2103	Capacitor	Not Used	Not Used	08T61630F26	Not Used
C2104	Capacitor	Not Used	Not Used	08T61630F26	Not Used
C2109	Capacitor	Not Used	Not Used	21S40655F20	Not Used
C2110	Capacitor	Not Used	Not Used	21S40655F20	Not Used
C2119	Capacitor	Not Used	Not Used	08T00015L18	Not Used
C2120	Capacitor	Not Used	Not Used	08T00015L18	Not Used
C2501	Capacitor	Not Used	Not Used	08T61630F34	Not Used
C2502	Capacitor	Not Used	Not Used	08T61630F34	Not Used
C2503	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C2504	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C2505	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C2506	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C2507	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C2508	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C2511	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C2512	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C2521	Capacitor	08T57851F21	08T57851F21	08T57851F24	08T57851F21
C3009	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C3010	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C3013	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C3014	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C4109	Capacitor	Not Used	Not Used	08T61642F27	Not Used
C4110	Capacitor	Not Used	Not Used	08T61642F27	Not Used
C6003	Capacitor	08T52448F41	08T57851F03	08T57851F03	08T57851F03
C6004	Capacitor	08T52448F41	08T57851F03	08T57851F03	08T57851F03
C7101	Capacitor	08T00125L04	08T00125L04	Not Used	08T00125L04
C7102	Capacitor	08T00125L04	08T00125L04	Not Used	08T00125L04
C7105	Capacitor	Not Used	Not Used	08T61642F12	Not Used
C7106	Capacitor	Not Used	Not Used	08T61642F12	Not Used
C7117	Capacitor	Not Used	Not Used	08T61630F22	Not Used
C7118	Capacitor	Not Used	Not Used	08T61630F22	Not Used

www.manualscenter.com

Symbol No.	Description	POWER SOURCE			
		JM● 100V Japanese	UL■ 120V North American	AM▲ 220V European	UN★ 120V Canadian
C7351	Capacitor	Not Used	Not Used	08T57851F24	Not Used
C7352	Capacitor	Not Used	Not Used	08T57851F24	Not Used
C7353	Capacitor	Not Used	Not Used	08T57851F24	Not Used
C7354	Capacitor	Not Used	Not Used	08T57851F24	Not Used
C7355	Capacitor	Not Used	Not Used	08T57851F24	Not Used
C7356	Capacitor	Not Used	Not Used	08T57851F24	Not Used
C7357	Capacitor	Not Used	Not Used	08T50579F26	Not Used
C7358	Capacitor	Not Used	Not Used	08T50579F26	Not Used
C7359	Capacitor	Not Used	Not Used	08T50579F26	Not Used
C7360	Capacitor	Not Used	Not Used	08T50579F26	Not Used
C9001	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C9002	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C9501	Capacitor	Not Used	Not Used	08S40805F05	Not Used
C9502	Capacitor	Not Used	Not Used	08S40805F05	Not Used
F1001	Fuse	65T55050F19	65T65292F03	65T42077U22	65T65292F03
F1301	Fuse	Not Used	65T66926F14	65T42077U08	65T42077U08
F1302	Fuse	Not Used	65T66926F14	65T42077U08	65T42077U08
F1303	Fuse	Not Used	65T66926F15	65T42077U08	65T42077U08
F1304	Fuse	Not Used	65T66926F15	65T42077U08	65T42077U08
F1305	Fuse	Not Used	65T66926F15	65T42077U15	65T42077U15
F1306	Fuse	Not Used	65T66926F18	65T42077U20	65T42077U20
J1001	Outlet, AC	09T67405F02	09T67405F02	Not Used	09T67405F02
J1002	Outlet, AC	09T67405F02	09T67405F02	Not Used	09T67405F02
J1003	Socket, Switch	Not Used	Not Used	09T51831F01	Not Used
L2101	Inductor	Not Used	Not Used	24T83130F02	Not Used
L2102	Inductor	Not Used	Not Used	24T83130F02	Not Used
L2103	Inductor	Not Used	Not Used	24T83130F02	Not Used
L2104	Inductor	Not Used	Not Used	24T83130F02	Not Used
P1001	Plug, AC Cord	28T67434F01	28T55335F02	28T43812P05	28T55335F02
P1002	Plug, Switch	Not Used	Not Used	09T51830F01	Not Used
Q3004	Transistor	48T81101F01	48S43525F05	48S43525F05	48S43525F05
Q4901	Tube	65T00091L03	65T00091L01	65T00091L01	65T00091L01
Q4902	Tube	65T00091L03	65T00091L01	65T00091L01	65T00091L01
R7341	Resistor	Not Used	06T00007L52	06T00007L52	06T00007L52
R7342	Resistor	Not Used	06T00007L52	06T00007L52	06T00007L52
RL1502	Relay	80T00048L01	80T83717F02	80T83717F02	80T83717F02
S1001	Switch	40T61963F02	40T61963F02	40T68579F01	40T61963F02
S1011	Switch	40T81345F01	40T83288F01	40T81345F01	40T92612F01
T1001	Transformer	25T81356F01	25T81356F03	25T81356F02	25T81356F03
7	Cover, Rear	15C81265F01	15C81265F05	15C81265F03	15C81265F07
20	Bush, Cap	43T53136F01	43T53136F01	Not Used	43T53136F01
26	Label, Fuse	54B62266F36	54B62266F53	54B62266F54	54B62266F53
31	Holder, Fuse	09T51960F01	09T51960F01	Not Used	09T51960F01
68	Assy., Front Panel	01V81600F58	01V83600F76	01V83600F76	01V83600F76
81	Label, Fuse	Not Used	54B62266F49	Not Used	Not Used

www.manualscenter.com

Symbol No.	Description	POWER SOURCE			
		JM● 100V Japanese	UL■ 120V North American	AM▲ 220V European	UN★ 120V Canadian
82	Label, Fuse	Not Used	54B62266F50	Not Used	Not Used
83	Label, Fuse	Not Used	54B62266F51	Not Used	Not Used
84	Holder, Fuse	Not Used	09T45548F01	09T45548F01	09T45548F01
85	Insulator	Not Used	Not Used	14A83125F01	Not Used
101-1	Owners, Manual	68P80130F59	68P81707F58	68P81707F59	68P81707F59
103	Carton, Packing	56S71001F74	56S71001F90	56S71001F90	56S71001F90

Semi-Conductor Lead Identifications

NJM78M12A : IC1119, 1120



1 : INPUT
2 : COMMON
3 : OUTPUT



M5220P : IC2101
M5238P : IC4101





M51320P : IC3001





www.manualscenter.com

NJM4558D : IC4102





TA7317P : IC501





2SA1015 : Q1101, 1111, 1114, 1116, 5105
2SC1815 : Q1112, 1113, 1115, 1501
2SC2240 : Q5101, 7307, 7308, 7311, 7312
2SA970 : Q5104, 7309, 7310



2SD1266 : Q1012

2SC2336 : Q1101
2SA1006 : Q1102



2SA1360 : Q1103, 1106, 1108, 1110, 7107, 7108
2SC3423 : Q1104, 1105, 1107, 1109, 7305, 7306
2SA1361 : Q7109, 7110



2SK30A : Q1117, 1118



2SK332 : Q2101, 2102



1. Drain
2. Gate
3. Source

2SJ75 : Q7101, 7102



1: DRAIN 1
2: GATE 1
3: SOURSE 1
4: DRAIN 2
5: GATE 2
6: SOURSE 2

2SA995 : Q7103, 7104
2SC2291 : Q7105, 7106



2SK405 : Q7301, 7302
2SJ115 : Q7303, 7304



www.manualscenter.com

LUX CORPORATION, JAPAN
1-1-8 Nishi Gotanda, Shinagawa-ku, Tokyo, 141 JAPAN
Phone: 03-494-1101 Telex: 8927-61

68P80574F02

6/87-S Printed in Japan